



BIS Hotel 5.7 Manual Instruction



Content

1. System Overview	5
1.1. System components	5
1.1.1. The door locks	5
1.1.2. General Lock Features	5
1.1.2.1. Deadbolt override	5
1.1.2.2. Cylinder for Mechanical Override (Optional).....	6
1.1.2.3. Common Doors	6
1.1.2.4. System Events	6
1.1.2.5. Lock Modes	6
1.1.2.6. Time-control.....	6
1.2. RFID card encoder.....	6
1.3. Hand held unit.....	7
1.4. BIS Software	7
1.4.1. Hardware requirements	7
1.4.2. The requirements for the PCs OS are:.....	7
2. Before software installation	7
2.1. In Win 7	8
2.2. Win 8	10
3. Software installations	11
4. Load software	16
5. Before programming a lock.....	18
5.1. Room type.....	18
5.2. Create rooms	19
5.2.1. Create guest room.....	19
5.2.2. Create inner door.....	22
5.3. Create Members	23
5.3.1. Create Emergency cards (Master key)	23
5.3.2. Staff card.....	25
5.4. Time card	26
5.5. Encoder driver installation	27
5.6. Encoder selection	30
6. Main steps to program a lock (With Cards)	30
6.1. System ID card (S50).....	30
6.2. Lock setting card (S50).....	33
6.3. Setup lock's time with Time card (S70)	35
6.4. Emergency cards (S50)	37
6.5. Staff card (S50).....	40
6.5.1. Setup Time section for staff cards.....	40
6.5.2. Issue "Staff card".....	41
6.5.3. Authoring staffs	43
6.6. Authorizing card (S70)	45
6.7. Assign member (Operator log in).....	46

7. Issue guest card	53
8. Back up database.....	56
9. Software registration	57
10. Hand held Unit.....	58
10.1. Hand held Unit profile	59
10.1.1. Function	59
10.1.2. Before Using	59
10.1.3. How to open and shut down.....	59
10.1.4. Manus of the hand held.....	59
10.1.5. Hand held operating steps for programming door lock	60
10.2. Driver installation	60
10.3. Options operation.....	65
10.3.1. Change password of handset (change pw of handset).....	65
10.3.2. Communicate with PC (communicate with PC)	65
10.4. Handset setting	65
10.4.1. Set time.....	66
10.4.2. Get time	66
10.4.3. Update SP	67
10.4.4. Delete data	67
10.5. Setting information	69
10.5.1. Correct room information.....	69
10.5.2. Correct authorization	69
10.5.3. Write handset.....	70
10.5.3.1. Time sections setting.....	72
10.5.3.2. Blacklist setting.....	72
10.6. Program the lock with handset	74
10.6.1. Setup system password (setup sys pw).....	74
10.6.2. Setup lock's information (setup lock's info)	74
10.6.3. Check lock's time (check lock's time).....	75
10.6.4. Adjust lock's time (adjust lock's time)	75
10.6.5. Check lock's battery (check lock's battery)	75
10.7. Audit trail lock's access records.....	75
10.7.1. Download lock's info (download lock's information).....	75
11. Trouble and Shooting	79
11.1. Run software error	79
11.2. Encoder is not working.....	79
11.3. Illegal card error	79
12. Emergency solution for lock.....	80
12.1. Frequently errors and Trouble Shooting Guide for Guest Card	80
12.2. Frequently errors and Trouble Shooting Guide for staff Card	81
13. Database type selection	82
13.1. Forget the operator password.....	83
13.1.1. Solution 1	83
13.1.2. Solution 2.....	83
13.2. Forget the system ID that ever set	83
13.3. Audit trail lock's information	84

13.3.1. Audit trail with Query card (S70).....	84
13.3.1.1. Issue query card.....	84
13.3.1.2. Read query card.....	86
13.3.2. Audit trail with Hand held.....	89
13.4. For a lost key card	90
13.4.1. Guest card	90
13.4.2. Staff card.....	90
13.4.3. Emergency card	90
13.5. Low voltage alarm.....	93
13.6. Door Ajar alarm.....	93

1. System Overview

1.1. System components

1.1.1. The door locks



1.1.2. General Lock Features

When a guest occupies a room, their complete privacy is insured by extracting a deadbolt. The deadbolt can only be retracted from outside the room with the (metal) Emergency Key (for locks with cylinders), a keycard with authorized deadbolt override,

Both the deadbolt and latch bolt can be retracted by use of a keycard authorized for deadbolt override. If no deadbolt override is assigned to the card, the indicator on the outside escutcheon, just above the card insertion slot, displays a yellow light when the card is inserted

1.1.2.1. Deadbolt override

A keycard can be authorized to override the deadbolt. Certain User Groups can be pre-defined to always have Deadbolt override. For Guest Keys it is also possible to set Deadbolt override as a tick off item in the Common Door list box. This means that the card is able to override the Privacy function (unlock when door is dead bolted).

The lock can always be opened by pressing the inner handle even if the deadbolt is extracted. This serves as an emergency exit

A new guest card automatically locks out the keycard of the previous guest. This is accomplished by assigning a start time to the card. When the card is issued, the system writes the present time onto the card.

Employee keycards work in parallel with the guest keycards. The employee keycards also are valid only for a specified amount of time. However, it is usually for a longer time than a guest keycard. Employee keycards are normally issued for access to one or several sections of rooms, depending on the hotel's needs, but keycards for bellboys can easily be encoded to allow access to individual rooms, like guest keycards. Employee access keycards do not override guest keycards and therefore do not affect a guest's access

1.1.2.2. Cylinder for Mechanical Override (Optional)

Most locksets may be equipped with a mechanical cylinder operated by the metal Emergency key (EMK). This cylinder will withdraw both latch and deadbolt when operated, and represents a dual independent emergency opening system, totally separated from the electronic lock controller.

1.1.2.3. Common Doors

Common Doors are typically perimeter doors, garage, health club, pool, VIP floors etc. This access is assigned automatically when the keycards are issued based on the settings in the System Setup Module. Up to 53 of these Common Doors can be specified in the VISION system.

Access to Common Doors is given in addition to doors that are specifically selected when the keycard is issued and up to 16 Common Doors can automatically assigned to a keycard when it is issued. For example, all Guest keycards might automatically include access through exterior entrances and parking

1.1.2.4. System Events

The BIS system keeps a constant log of every computer transaction. The log is recorded to the hard disk. The log may be recalled from computer memory at any time by running a system event report. Reports may include every computer entry or may be limited to a given room or a given user. Logged data are time of event, name of operator and details about the command issued.

1.1.2.5. Lock Modes

Locks can be set to operate in 2 different modes.

Normal Mode—the door is locked and unlocks when a valid keycard is withdrawn.

Passage Mode—the door will alternate between locked and unlocked whenever a valid keycard is inserted

1.1.2.6. Time-control

All keycards include a start and expiration date

1.2. RFID card encoder

It is used for reading and writing cards



RW-41

1.3. Hand held unit

The Hand held unit brings information from BIS database to the locks when the system is started for the first time (configuration and initialization) and brings information from the lock to BIS when you want to see the information of the lock.



RD-Z08A

1.4. BIS Software

The BIS software comes on a CD. The software can be installed on any PC running Windows 98, 2000, NT, XP, Vista, Win 7, Win 8, Win sever 2003, Win server 2008.

1.4.1. Hardware requirements

Most common brand PCs that meet the requirements for Windows98, 2000, NT, XP, Vista, Win 7, Win 8, Win sever 2003, Win server 2008 can be used


1.4.2. The requirements for the PCs OS are:

Windows 98/NT/2000/XP/Vista/7/8

2. Before software installation

Closing UAC is necessary before installing be-tech locking system, otherwise you will get an error while running the software, and then you can not use the software. Please see below to close in Win 7 and Win 8.


2.1. In Win 7



Press “Star” in the Win 7, you see the screen as below, and then type “UAC”




You see “Change User Account control Settings”, click it




Choose "Never notify", and press "OK", restart your computer.


2.2. Win 8




Choose "Never notify", and press "OK", restart your computer.



3. Software installations





Find out Be-tech installation “exe” file and double click.





Double click the file and prepare to install

Click **Next**





Choose language of the software




Enter the use name and company name.


Click "Next"





Note:


For OS Win 8, please install the software locating in other local disk except C:, otherwise that would be some little problem when you run the software. The problem is caused by the security level of Win 8, not by BIS software.






Choose "Custom"
And
Click "Next"







After installation, you will see the icons




4. Load software



Double click the icon ,




If you can't run the software in QS Win 8, please right click "BIS Hotel 5.7" and select "Run as administrator"




Select the application language.

The dialogue will not pop up if select "Don't show this dialog again"




There are two databases available for Be-tech locking system, "Microsoft Access" and "SQL Server", Ms ACCESS is for stand alone computer to issue card, which is contained after installing the software.



Before using SQL servers, you have to install SQL database first.

SQL database is for multi-computers to issue cards, regarding to how to run SQL, please contact us for more information.

Click "OK", you will see the screen shows as below






If you did not setup the operator, then you can continue as clicking "OK", you will see as below


5. Before programming a lock

Before programming a lock, make sure all of the information is ready, such as room types, room numbers, time sections, emergence cards, staff cards are completed.

5.1. Room type




Choose the “Type ID” and enter “Type Name”, and click “Add”



After adding all the “Room Types”, you will see the “Room Types” showing on the software.

5.2. Create rooms





5.2.1. Create guest room


There are two types of room in the “Rooms Create”, one is “All Rooms” which is normally for guest

room or some special rooms that allows specified person to getting in; the other is “All Public Doors” which allows all guests and hotel staffs to get in, please find out the “MJM instruction” for further instructions.


“All rooms” is normally for setting guest room.





Left click “All Rooms” to make the ground color is blue  , and then click “Create Level”, the “New Building” is created. If you want to create more buildings, return to left click “All Rooms” to make the ground color is blue and click “create level”. Right click “New Buildings” to delete or rename.



, but “All Room” is only can be renamed, can't be deleted.




Left Click “New Building” to make the ground color is blue  , and then click “create room”




You can change “Name Template” and “ID Template”

Due to every floor own 10 rooms that we should set the total number to 10. The door name set to “10##”, the door ID set to “1000##”, both of their start number is “1”. Click the **Apply** button to finish the operation. Follow the above steps to add all the rooms of each floor.





Choose the room and right click, setup the room type. You can select all rooms or one by one.



5.2.2. Create inner door

The inner door function is for normally for some big room which has an inner room. Choose the room which has the inner room and then click to make the ground color is blue, and then click “create inner room”



BIS Hotel v5.7A

Setting Operate View Members Handset Guests Cards Data Help Language



Reader Check Members Operators FD Terminal Print View Relogin Exit

All Rooms Single Double

Door Name	Door ID	Open Dura...	Total C...	Total Reco...	Guest SN	Total Guests	Room Type	Room Status	Batteries Chang.
1001	100001				0	Vacant	Single	Clean Vacant	
1002	100002				0	Vacant	Single	Clean Vacant	
1003	100003				0	Vacant	Single	Clean Vacant	
1004	100004				0	Vacant	Single	Clean Vacant	
1005	100005				0	Vacant	Double	Clean Vacant	
1006	100006				0	Vacant	Double	Clean Vacant	
1007	100007				0	Vacant	Double	Clean Vacant	
1008	100008				0	Vacant	Double	Clean Vacant	
1009	100009				0	Vacant	Double	Clean Vacant	
1010	100010				0	Vacant	Double	Clean Vacant	
1010_01	10001001				0	Vacant	Double	Clean Vacant	
2001	200001				0	Vacant	Single	Clean Vacant	
2002	200002				0	Vacant	Single	Clean Vacant	
2003	200003				0	Vacant	Single	Clean Vacant	
2004	200004				0	Vacant	Single	Clean Vacant	
2005	200005				0	Vacant	Single	Clean Vacant	
2006	200006				0	Vacant	Double	Clean Vacant	
2007	200007				0	Vacant	Double	Clean Vacant	
2008	200008				0	Vacant	Double	Clean Vacant	
2009	200009				0	Vacant	Double	Clean Vacant	
2010	200010				0	Vacant	Double	Clean Vacant	
2010_01	20001001				0	Vacant	Double	Clean Vacant	

5.3. Create Members


Click “Members”, choose “Member Management”





There are three items in “member Management”

All Emergency cards, All staff cards, All temporary card

5.3.1. Create Emergency cards (Master key)




Right Click “All Emergency Cards”, you will see the options, and then click “Create Group”, “new group” is created. The cards in this group can open locks freely, without any limitations.



Create the members of “All Emergency Cards”


A window will turn up, now the window requires you to fill in the member information. After all the information has been registered, click the **Apply** button to finish the procedure and click the **Cancel** button to return to the system. Follow the above steps to add all the members into the system.



Notice:

Every Member code template is the unique and it is a sign of member. So before the adding, please assign the code template to every member by a plan.

5.3.2. Staff card





Staff cards are normally for the employees in the hotel, like house keeping, it is controlled by time and Door numbers.


5.4. Time card

Time section is use to analyze the work time. Only the corresponding work time could be accept to open the door. At this case, we divide the Sunshine hotel work time into six sections like this:

Morning shift	Middle shift	Night shift	Morning shift	Middle shift	Night shift
8:00-16:00	16:00-00:00	00:00-8:00	8:00-16:00	16:00-00:00	00:00-8:00
Monday to Friday	Monday to Friday	Monday to Friday	Sat Sun	Sat Sun	Sat Sun






After the menu pop up, select Time Section1, the time writes 16:00-24:00, the day select the Monday to Friday, then press the **Issue** button to make a time card, make all the left time sections like the above procedures.





5.5. Encoder driver installation

Insert the encoder, there will be a window popping up “found new hardware”, you need to install the driver, if there is nothing popping up, you need to find out device manager to fix the driver installations.







Right click




Follow the guidance to find out the RW-41 folder.



After a while, driver installs complete, you will see the encoder details in the Device Manager

5.6. Encoder selection





6. Main steps to program a lock (With Cards)

Making a lock accept key cards, there are four key points are required.

1. System ID card
2. Lock setting card
3. Time card
4. Authorizing card

6.1. System ID card (S50)





● **Sector**


what we use for our locking system are 0.1.2 sectors, normally defaulted sector is “0” which is for locking system, “1” is for lift control system, “2” is spare sector.

● **Using for setting the initialized locks**

It needs to be selected as the lock is reset or the lock is newly installed.

● **Reset system password (need to restart)**


The system returns to Be-tech’s password.




Enter 6 digits system password (numbers only), and click using for setting the initialized locks, and then click “issue”.

Note:


1. If you just test something of the lock, please do not change the system ID, otherwise the cards can not be used anymore in new software.
2. Issuing a system ID card with changing password is normally for the hotel that has been completed already.
3. The previous cards without changing system ID can not be used to open the doors in the same hotel after new system ID is set.




Click "OK"



Click "OK"



Click 'OK"



If you already changed the password, you will see red words saying "system password has been changed 1 times", it means you have already changed the password for 1 time


Explanation of System password: Software, key card, lock, and hand held, their original system password has been set; we call it “Be-tech password”. (However, clients no need to know what the original password is).

Why we need to change the system password?


Due to there are so many clients all over the world, all locks are with “Be-tech password”, they are not safe that we can open all doors as if we keep a general card, we have to issue a new system ID card to change the system ID, then new system is no more “Be-tech password”. The system ID is changed, and all relative components must be matched with system ID so that the whole system is working.

6.2. Lock setting card (S50)

Lock setting card is used for setup lock’s information, such as lock number, lock memory, motor parameter.



Select one room, right click and find out “lock setting”



- **Lock memory**

It is used for setting up staff card and access records’ amount. Total card number is for staff card amount, the defaulted value is 50.

- **Motor parameter**

It is for setup mortise parameters, no need to change them.

- **Set to passage**


Passage means the lock won’t lock automatically after unlocking.

- **Set to latch bolt alarm**

Latch bolt alarm is for avoiding door does not close well. If latch is hanged, lock will sound “Be, Be.....”


- **Reset data (using for setting initializing locks)**

Reset previous records and data, such as access records, guest SN, staff card amount.....




You can see all information before you issue the card

Click “OK” to issue card.





Scan the lock with lock setting card, green light and 1 beep from the lock means lock ID is set to the lock.


Note: If you have 100 rooms, you have to issue 100 times lock setting card, because every door with different room NO., we have to issue different cards to set up different rooms. However, 100 times is not meaning 100 cards, you can issue the lock setting cards with only 1 card. For example, you already issued the lock setting card for room 000001, and then take the card to scan the door, 1 beep, green light, setting is OK, and at this time the room is 000001. To setup room 000002, we can use a new card or the 000001 lock setting card, after issuing, the door ID would be changed 000002, at this time the lock setting card is 000002. And then scan the door, 1 beep, green light, setting is OK, and the door ID is 000002. Even though the previous ID is 000001, after scanning the ID 000002 and the door will change into ID 000002





If you use handset, you can select all rooms and click “locking setting card”, and then click “Save”, you will see all rooms have been set.

6.3. Setup lock’s time with Time card (S70)








Time offset is the time you would spend to get to the room after issuing Time card.







Note: The time in the card will not move. You need to scan all of the locks within 10 minutes, otherwise, you need to re-issue time card. Green light and 1 beep from the lock mean Time is set to the lock.


6.4. Emergency cards (S50)

Emergency cards: it can open the door without any limitations.



Update card No.: if the software is newly installed without and data, so the option is chosen as default. After issuing, there will be a card NO.






The screenshot shows a software window titled "Member Management". At the top, there is a menu bar with "Operate", "View", and "Cards". Below the menu bar is a toolbar with icons for "Check", "Print", "View", and "Close". The main area of the window is divided into two parts. On the left is a tree view with the following items: "All Emergency Cards", "New Group", "All Staff Cards", "New Group", and "All Temporary Cards". On the right is a table with the following columns: "Member Name", "Member Code", "Member No", "Start Time", "Terminating Ti...", and "Card No". The table contains three rows of data, each with a key icon to the left of the Member Name.

Member Name	Member Code	Member No	Start Time	Terminating Ti...	Card No
0001	0000000001	1			427592023
0002	0000000002	2			427592061
0003	0000000003	3			427592068



After issuing the cards, these cards are able to open door.






Member Name	Member Code	Member No	Time Section	Working Time	Working Day
0004	0000000004	4	Time Section1	00:00-24:00	All Days
0005	0000000005	5	Time Section1	00:00-24:00	All Days
0006	0000000006	6	Time Section1	00:00-24:00	All Days
0007	0000000007	7	Time Section1	00:00-24:00	All Days

You can select all staffs to setup the time section if they are in a same work section.

6.5.2. Issue “Staff card”,





Member Management											
Member Name	Member Code	Member No	Time Section	Working Time	Working Days	Public Do...	Start Time	Terminating Ti...	Card No		
0004	0000000004	4	Time Section1	00:00-24:00	All Days	Cannot D...	7/16/2013	7/16/2014	427249605		
0005	0000000005	5	Time Section1	00:00-24:00	All Days	Cannot D...	7/16/2013	7/16/2014	427249686		
0006	0000000006	6	Time Section1	00:00-24:00	All Days	Cannot D...	7/16/2013	7/16/2014	427249694		
0007	0000000007	7	Time Section1	00:00-24:00	All Days	Cannot D...	7/16/2013	7/16/2014	427249701		

However, card can't open the door right now; even you already issued the card.


6.5.3. Authoring staffs

Right click and choose "Authoring....."




If you want to authorize staff 1 to open new building 1, just click new building

If you want to authorize staff 1 to open some of the rooms, so you need to select the door name as you want on the right.




However the staff card can't open the door right now, even though you have issued the card, so you need to issue authorizing card to scan the door, after that the staff card can be used. Please find out the authorizing card.

6.6. Authorizing card (S70)




The screenshot shows a software interface with a menu bar (Setting, Operate, View, Members, Handset, Guests, Cards, Data, Help, Language) and a toolbar (Reader, Check, Members, Operators, FD Terminal, Print, View, Relogin, Exit). Below the toolbar are tabs for 'All Rooms', 'Single', and 'Double'. A tree view on the left shows a hierarchy of rooms. The main area contains a table with columns: Door Name, Door ID, Open Dura..., Total C..., Total Reco..., and Guest S. A context menu is open over door 101, with 'Authorizing Members...' highlighted in red. The menu items include: Check-in (Ctrl+G), Check-out, Lock Setting... (Ctrl+L), Authorizing Members... (Ctrl+U), Delete (Del), Rename, Room Status, Change Batteries..., Change Guest Serial No..., and Default Public Doors...

Door Name	Door ID	Open Dura...	Total C...	Total Reco...	Guest S
1001	100001	3(Sec.)	50	414	0
1002	100002	3(Sec.)	50	414	0
1003	100003	3(Sec.)	50	414	0
1004	100004	3(Sec.)	50	414	0
1005	100005	3(Sec.)	50	414	0
1006	100006	3(Sec.)	50	414	0
1007	100007	3(Sec.)	50	414	0
1008	100008	3(Sec.)	50	414	0
1009	100009	3(Sec.)	50	414	0
101			50	414	0
101			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
200			50	414	0
201			50	414	0
201			50	414	0



The screenshot shows a tree view of rooms. The root is 'All Rooms', which branches into 'New Building' and 'All Public doors'. Under 'New Building', there are several sub-rooms, each containing a list of doors (e.g., 0006, 0007, 2010, 0004, 0005, 0006, 0007). The '2010' room is expanded, showing a sub-room '2010_01' with doors 0004, 0005, 0006, 0007. The '1010_01' room is also expanded, showing doors 0004, 0005, 0006, 0007.



Click "Issue", and take the card to scan the door, after that staff cards are able to open the door.



The screenshot shows a dialog box with two buttons: 'Issue' and 'Cancel'. The 'Issue' button is highlighted with a red box. Below the buttons, it says 'Total selected doors 22'.

6.7. Assign member (Operator log in)

You can setup operator's permission



Operator Group Properties [X]

Group code:

Group name:

Description:

Operator Group Properties [X]

Group code:

Group name:

Description:

Assign Operators [X]

Operate

Print Close

Group Code	Group Name	Description
001	GM	1

Operator Code	Operator Name	Description
---------------	---------------	-------------

[X]

001 GM 1

- Create Group
- Create Operator**
- Delete Del
- Permissions...
- Properties

Operator Code	Operator Name	Description
---------------	---------------	-------------

Operator Properties [X]

Operator code:

Operator name:

Description:

Login password:

Confirm password:

[OK] [Cancel]

Operator Properties [X]

Operator code:

Operator name:

Description:

Login password:

Confirm password:


Assign Operators [-] [□] [X]

Operate


Print Close

Group Code	Group Name	Description
001	GM	1


Operator Code	Operator Name	Description
01	kelly	GM1



Set the permissions of operator.




According to customer's requirement, you can set the permissions of the user.



After setup the operators, you have to enter operator code and login password to access software

● No permission



BIS Hotel v5.7A

Setting Operate View Members Handset Guests Cards Data Help Language


Reader Check Members Operators FD Terminal Print View Relogin Exit

All Rooms Single Double

Door Name	Door ID	Open Dura...	Total C...	Total Reco...	Guest SN	Total Guests	Room Type	Room Status
1001	100001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1002	100002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1003	100003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1004	100004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1005	100005	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1006	100006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1007	100007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1008	100008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1009	100009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1010	100010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1010_01	10001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2001	200001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2002	200002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2003	200003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2004	200004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2005	200005	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2006	200006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2007	200007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2008	200008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2009	200009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2010	200010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2010_01	20001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant

You can operate all of the options in the software.

● With permissions



When you enter the operator that with permissions, so you will see there would be some options you can't run.

BIS Hotel v5.7A


Setting Operate View Members Handset Guests Cards Data Help Language

Reader Check Members Operators FD Terminal Print View Relogin Exit

All Rooms Single Double


	Door Name	Door ID	Open Dura...	Total C...	Total Reco...	Guest SN	Total Guests	Room Type	Room Status
	1001	100001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	1002	100002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	1003	100003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	1004	100004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	1005	100005	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	1006	100006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	1007	100007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	1008	100008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	1009	100009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	1010	100010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	1010_01	10001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	2001	200001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	2002	200002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	2003	200003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	2004	200004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	2005	200005	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
	2006	200006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	2007	200007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	2008	200008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	2009	200009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	2010	200010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
	2010_01	20001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant

7. Issue guest card



Door Name	Door ID	Open Dura...	Total C...	Total Reco...	Guest SN	Total Guests	Room Type	Room Status
1001	100001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1002	100002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1003	100003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1004	100004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
1005	100005	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1006	100006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1007	100007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1008	100008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1009	100009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1010	100010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
1010_01	10001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2001	200001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2002	200002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2003	200003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2004	200004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2005	200005	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant
2006	200006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2007	200007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2008	200008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2009	200009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2010	200010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant
2010_01	20001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant

Make sure System ID, lock setting, Time, authorizing are done, double click the room number in the software, you will see guest card screen as below



Selected Rooms

Door Name	Door ID	Guest SN	Total Guests	Room Status
<input checked="" type="checkbox"/> 1001	100001	0	Vacant	Clean Vacant

Guest Index:

Card Information

Staying Days:

Arrival Time:

Departure Time:

Holder Details

Guest ID:

Guest Name:

Nationality:

Date of Birth:

ID Document Name:

Contact Address:

Zip Code:

Telephone No.:

Remark:

Sex: None Married

Place of Birth:

ID Document No.:

E-Mail:

Fax No.:

Buttons: >> Check-in Extend Check-out **Issue** Modify Confirm Cancel

Total selected room(s) 1 Total guest(s) 1 Operator


You can set the valid time of the guest, and click "Issue",




Card Information

Card Type:	Guest Card
Card No:	Not Issued
Guest ID:	None
Guest Name:	None
Guest SN:	427595503
Guest Index:	1
Door Name:	1001
Door ID:	100001
Inner Doors:	Unable to open
Public Door:	Unable to open
Start Time:	7/19/2013 11:59:00 PM
Terminating Time:	7/20/2013 12:30:00 PM
Card Options:	Cannot open double-lock
Issuer ID:	01
Issued Time:	2013-07-20 00:31:43

OK Cancel



Information


 Guest Card issued, please take out the smart card.

OK

Guest card is done, then take this card to the corresponding room, try to open the lock. Green light and 1 beep, motor run from the lock, so you can push the handle.

BIS hotel with a new function: FD Terminal.

Note: When you make a reservation for a room, the room can not be occupied until the check-in date.




The screenshot shows the BIS Hotel v5.7A software interface. The 'FD Terminal' menu item is highlighted with a red box. Below the menu, there is a table with the following columns: Door Name, Door ID, Open Dura..., Total C..., Total Reco..., Guest SN, Total Guests, Room Type, Room Status, and Batteries Chang... The table lists various rooms with their respective IDs and statuses.


Door Name	Door ID	Open Dura...	Total C...	Total Reco...	Guest SN	Total Guests	Room Type	Room Status	Batteries Chang...
1001	100001	3(Sec.)	50	414	427595503	1	Single	Occupied	
1002	100002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
1003	100003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
1004	100004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
1005	100005	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1006	100006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1007	100007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1008	100008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1009	100009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1010	100010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1010_01	10001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2001	200001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2002	200002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2003	200003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2004	200004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2005	200005	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2006	200006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2007	200007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2008	200008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2009	200009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2010	200010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2010_01	20001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	



8. Back up database

When all of setup is done in the software, backup the database is necessary.






It is necessary to back up the database to another place, such as another computer or USB storage, in case that the computer is broken, you can get the back up in other place.

9. Software registration



Normally, there will be user register in 30 days after you install the software. In that case, you need to have the software registered; so please send this user code to Be-Tech for a registered code. Otherwise, you can't use the software anymore out of 30 days.

Note: The user code will be changed when close it and re-start. Different user code is required different registered code.



If you want to have the software registered after software installed, you can click "Help" and

“Register”, then you will see the “User register”



10. Hand held Unit





White wire for PC, black one for lock

10.1. Hand held Unit profile

10.1.1. Function

Hand held unit is used for setting lock, and audit trail the information, it will make you more convenient to setup the lock, if you have hand held, and you no need issue lock setting card, authorizing card, and time card.

10.1.2. Before Using

First, before using hand held, make sure SID card, all the rooms and members have been setup.

Second, our handheld is available for Win XP/VISTA/7/8

10.1.3. How to open and shut down

Turn on: Press "*" about 3 seconds. After one "beep", the LCD shows entry window meaning that handheld is on.

Turn off: Press "*" about 3 seconds. After one "beep", the handset is off.

10.1.4. Manus of the hand held

When open the handheld, there is a Be-tech logo, Press "OK" key in entry window, and then follow the indication to enter the correct password and press "OK" key for logging in, you will see 8 options:

- **Change password of handset (change pw of handset)**
- **Communicate with PC (communicate with PC)**
- **Setup system password (setup sys pw)**
- **Setup lock's information (setup lock's info)**
- **Check lock's time (check lock's time)**
- **Adjust lock's time (adjust lock's time)**
- **Check lock's battery (check lock's battery)**
- **Download lock's info(download lock's information)**



10.1.5. Hand held operating steps for programming door lock



Driver installation---handset settings---Setting information



Please follow the detailed instructions to make all of the steps down as below.



10.2. Driver installation

Connect the handheld to the computer, and find out the "communicate with PC, there will be a screen pops up.









10.3. Options operation

10.3.1. Change password of handset (change pw of handset)

Function: The default password of handset is blank. After changing password of handset, users must access to handset with the correct password next time.

Operation: choose this option, press "OK", enter a new password, press "OK", confirm the new password, press "OK", done.

10.3.2. Communicate with PC (communicate with PC)



Function: setup the handset on PC such as setting time, querying information, deleting date and so on.

Operation: connect with pc with appropriate line, and then choose this option, press "OK", done.

And the LED will show "Waiting for communication.....", if connection is faulty, it will show "connection failure"


10.4. Handset setting

Make sure handset is communicating with PC and under "Waiting for communication....." Then go back to the software, find out the handset, select "handset setting"




10.4.1. Set time

Set up handset's time




10.4.2. Get time

Check handset's time




10.4.3. Update SP

Update handset's SID as software SID, it means that the handset must have the same SID with software, if their SID is different, the key cards issued for encoder could not open the door.



10.4.4. Delete data

Delete the old data of the handset, it will take about couples minutes.



HandSet Setting ✕

HandSet Time: 2011-03-14 14:15:38

System Time: 3/14/2011 ▼ 2:17:08 PM ↕

Reset initialized system password

Set Time Get Time Update SP Delete Data Cancel

Operation Status ■ 7%

10.5. Setting information

Make sure handset is communicating with PC and under “Waiting for communication.....”

It is used for writing information from the software to handset. Before write handset, make sure all of the rooms information is done, such as room information, authorization information.


10.5.1. Correct room information

Room information must be set as below; otherwise you can not see the rooms when you are going to write the handset. (Please find out the settings in BIS Hotel 5.7)

Door Name	Door ID	Open Dura...	Total C...	Total Reco..	Guest SN	Total Guests	Room Type	Room Status	Batteries Chang...
1001	100001	3(Sec.)	50	414	427595503	1	Single	Occupied	
1002	100002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
1003	100003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
1004	100004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
1005	100005	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1006	100006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1007	100007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1008	100008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1009	100009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1010	100010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
1010_01	10001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2001	200001	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2002	200002	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2003	200003	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2004	200004	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2005	200005	3(Sec.)	50	414	0	Vacant	Single	Clean Vacant	
2006	200006	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2007	200007	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2008	200008	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2009	200009	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2010	200010	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	
2010_01	20001001	3(Sec.)	50	414	0	Vacant	Double	Clean Vacant	



10.5.2. Correct authorization

Authorization information must be set as below; otherwise you can not use the staff card to open the door. (Please find out the settings in BIS Hotel 5.7)




10.5.3. Write handset


Then you can set information to handset.




When you press “OK”, you will see all rooms on the left, basically, we choose all room and move them to right, so you press “ >> ”



If you want to choose only one room, press “ > ”




Press "next"




10.5.3.1. Time sections setting

Press “set”, you will many time sections you can set, it is like the “time card”, choose “Reset guest information” if locks are newly installed. And other two options depend on requirement.



10.5.3.2. Blacklist setting

If some card is lost, in that case, you need to choose the lost card, and take it into right, and that card can not be used as all the information is transmitted into the locks. Then, press “next”,



Set Lock Information

Blacklist setting:

Card Type	Card No	Door ID	Holder Nam	Card Type	Card No	Holder N
Emergen...	353428280		0001			
Staff Card	353428969		0002			
Staff Card	353428393		0005			
Staff Card	353428387		0004			
Staff Card	353428378		0003			
Staff Card	334416583		0002			

Confirm

Do you want to write handset?

Yes No Cancel

Total Blacklists: 0

Set Conditions...

<< Back Next >> Cancel

Total Select Rooms: 22 Operation Status

Set Lock Information

Blacklist setting:


Card Type	Card No	Door ID	Holder Nam	Card Type	Card No	Holder N
Emergen...	353428280		0001			
Staff Card	353428969		0002			
Staff Card	353428393		0005			
Staff Card	353428387		0004			
Staff Card	353428378		0003			
Staff Card	334416583		0002			

Total Blacklists: 0

Set Conditions...

<< Back Next >> Cancel

Total Select Rooms: 22 Operation Status: 34%



When you see “write handset successfully”, all the information of the hotel has been transmitted in the handset. The next step is going to set up the locks.

10.6. Program the lock with handset

10.6.1. Setup system password (setup sys pw)

Function : Setup/change system password of the lock.

Operations:

Insert the USB-Mini USB wire, then go in front the lock, there is Mini USB socket at the bottom, connect handset with lock, then choose “ setup sys pw”---- “OK” ----“1 beep, green light” comes from lock, setting is successful. Then move to “setup lock’s info”

10.6.2. Setup lock's information (setup lock's info)

Function: setup/change lock's information including lock's memory, motor's parameter, authorizing staffs, blacklist and so on.

Operation:

Choose “setup lock’s info”, press “OK”, you will see enter lock’s No., in that case, you can enter the locks’ No, and press “OK”, the lock’s No. is with 8 digits, the ahead 6 digits is same as “Door ID” in the software, and the last two digits are for inner door, without inner door is “00”, for example, if you want to find out the door ID is 100001 to set, the Door ID in the software is 100001, there is no inner door in this room, so you enter 10000100; if there is one inner room in Door ID 200002, then you can enter 20000201 to find out that room No. And then, press “OK”----“1 beep, green light” comes from lock, done.

In another case, once you see “enter lock No.”, keep pressing “OK”, you will see all the rooms; find out the corresponding room, press “OK”----“1 beep, green light” comes from lock, done.

10.6.3. Check lock's time (check lock's time)

Function: Check lock's current time.

Operation: Connect the lock with appropriate line, then choose this option, press "OK", done.

10.6.4. Adjust lock's time (adjust lock's time)

Function: Set the current time to the lock.

Operation: connect with lock with appropriate line, and then choose this option, press "OK", confirm the time and press "OK", done.

This is another important step for setting the lock, it is used for setting lock's time, then choose "adjust lock's time"---- "OK" ----"1 beep, green light" comes from lock, setting is successful, if you want to sure if the time has been set, you can use "check lock's time".

10.6.5. Check lock's battery (check lock's battery)

Function: Check lock's current battery.

Operation: Connect the lock with appropriate line, then choose this option, press "OK", it will display normal/low.

10.7. Audit trail lock's access records

10.7.1. Download lock's info (download lock's information)


Function: download the current opening record of lock to handset

Operation: connect with lock with appropriate line, then choose this option, press "OK", wait for a moment, done.


Connect the lock with handset, choose the option, and press "OK", it will take couples seconds to download the information from the lock.

After downloading the information, connect the handset with PC, and choose "communicate with PC",


Go back to the software, find out the "Handset", and choose "query information", you will see the screen as below, and then press "OK".



Press "read data"





Press "Yes".




Notice: Do not move the device or load any other operation in PC when downloading the information.

After downloading the information, you will see the screen as below, click the room you want, and then press "Query",







When "Read handset successfully" pops up, press "OK", you will see another screen as below,



Choose the room and right click the mouse, and you will see "view", press "view", finally, you can see all the information of the lock.





Query Room

- 1001 3/15/2011 10:11:49 AM

Temporary Cards | Staff Cards | Access Records

Lock Information | Time Sections | Terminating Cards

Lock ID

- Door Name: 1001
- Door ID: 100001
- Inner Door: Not Inner Door
- Public Door: Not Public Door
- Passage
- Electro-locking
- Lock Time: 11-03-15 10:11:49
- Memory
 - Max. of Staff Cards: 50
 - Max. of Access Records: 414
- Motor
 - Rotated(MSEL): 160
 - Reversed Length(MSEL): 160
 - Open Duration(Seccs.): 3
- Gust

Current query room name: 1001

Read Data | Print | Save | Cancel


Total Rooms: 1 | Read Status: 0%

start | MF57 | 11:04 AM

Notice: one handset can download several locks' information. But need to view the information one by one.


11. Trouble and Shooting

11.1. Run software error



Solution: Close the UAC following "2. Before software installation"

11.2. Encoder is not working




Solution: Check if the driver is installed


Check if the care is put on the encoder

Check if the ecoder model is correct

11.3. Illegal card error




Reason: The card's system ID is different from software's. Check if the software is changed system ID. If the software is not changed system ID (as below), the card is ever changed system ID. In this case, you have to use another new cards.




12. Emergency solution for lock

There are error indications for our lock; different sound and different light are indicating different errors.

12.1. Frequently errors and Trouble Shooting Guide for Guest Card




12.2. Frequently errors and Trouble Shooting Guide for staff Card





13. Database type selection

When you login to the software, wrong database type is selected, in that case, follow the instructions as below to re-select the database.



Right click the Icon.





Delete “setup”, and re-run the software, you will see the database selection.

13.1. Forget the operator password

13.1.1. Solution 1

Please send to us the database, and we will get it for you.

13.1.2. Solution 2

Open the database, find out “Operator”, delete the operators inside the table, and re-create the operator.

13.2. Forget the system ID that ever set


Please send the database to us via e-mail with a compressed file, be-tech will give you respond soon

13.3. Audit trail lock's information


13.3.1. Audit trail with Query card (S70)

13.3.1.1. Issue query card


There are total 3 cards need to be issue, because only one card is not large enough capacity to contain all information of lock.




Click "Issue"




Click "OK",




Click "OK", in about 1 min




Click "OK",



Click "OK", in about 1 min




Click "OK"




Click "OK", in about 1 min

Take the three cards from A to C to scan the lock. The lock will be "1 beep, green light" after scanning the lock meaning read data successfully. However one of them is fail, please re-try again.


13.3.1.2. Read query card




Click "Query"



Click "OK"




Click "OK"




Click "OK"

Note: If one of them can't be read, the audit trail is unsuccessful. In that case, please re-try again.



You will see the six pieces information as below,



Query Card

Card No	Holder Name	Holder Name

Start address: 0x01D0 Active pointer: 0x01D0 Max number: 76 Total number: 0



Filter invalid datas

Query Card

Card Type	Acc...	Card No	Holder Name	Access Time	Issuer Code	Iss
Staff Card	52	354986714	0003	4/3/2011 11:56:47 AM	01	4/3
Staff Card	51	354986714	0003	4/3/2011 11:56:43 AM	01	4/3
Staff Card	50	354986714	0003	4/3/2011 11:56:39 AM	01	4/3
Staff Card	49	354986714	0003	4/3/2011 11:56:34 AM	01	4/3
Staff Card	48	354986714	0003	4/3/2011 11:56:30 AM	01	4/3
Staff Card	47	354986714	0003	4/3/2011 11:56:26 AM	01	4/3
Staff Card	46	354986714	0003	4/3/2011 11:56:21 AM	01	4/3
Staff Card	45	354986714	0003	4/3/2011 11:56:17 AM	01	4/3
Staff Card	44	354986714	0003	4/3/2011 11:56:13 AM	01	4/3
Staff Card	43	354986714	0003	4/3/2011 11:56:08 AM	01	4/3
Staff Card	42	354986714	0003	4/3/2011 11:56:04 AM	01	4/3

Start address: 0x0620 Terminating address: 0x2000 Active pointer: 0x0960 Max number: 414

Filter invalid datas



13.3.2. Audit trail with Hand held

Please find out “10. Hand Held Unit—10.7 Audit trail lock’s access records”

13.4. For a lost key card

13.4.1. Guest card

Just check out the room, and issue a new guest card to open the door, the lost one is canceled.

13.4.2. Staff card

- **Solution 1**

Re-issue a staff card by update card number to open the doors, the lost one is canceled



- **Solution 2**

Re-issue a staff card by update card number to open the doors, if you the card can't open the door, you need to authorize again.


13.4.3. Emergency card

Terminating card (S70 card) or hand held is required

- **Terminating card (S70)**




Find out the card that lost




The 'Refreshing Conditions' dialog box contains a list of optional fields. The 'Card Type' checkbox is checked and highlighted with a red box. The 'Issued Time' checkbox is unchecked and also highlighted with a red box. The SQL query for 'Card Type' is 'issuedcards.card_type IN ('C','G','D','P')'. The SQL query for 'Issued Time' is 'issuedcards.issued_time BETWEEN #2013-0;'. 'OK' and 'Cancel' buttons are at the bottom.

Do not click "Issued Time"




The 'Field Condition' dialog box shows a list of card types. 'Emergency Card' is selected and highlighted with a blue bar, and its checkbox is checked and highlighted with a red box. Other options are 'Guest Card', 'Staff Card', and 'Temporary Card'. 'OK' and 'Cancel' buttons are at the bottom, with 'OK' highlighted by a red box.


Just click "Emergency card"




The 'Refreshing Conditions' dialog box is shown again. The 'Card Type' checkbox is checked and highlighted with a blue box. The 'Issued Time' checkbox is unchecked and highlighted with a blue box. The SQL query for 'Card Type' is 'issuedcards.card_type IN ('C')'. The SQL query for 'Issued Time' is 'issuedcards.issued_time BETWEEN #2013-0;'. 'OK' and 'Cancel' buttons are at the bottom, with 'OK' highlighted by a red box.



You will see the emergency cards that you ever issued.



Select the lost emergency card make it to the left window



Put a S70 card on the encoder, click "Issue". Scan all of rooms with this Terminating card after issuing; the lock emits 1 beep and green light, operation is successful, the lost card can not open the lock any more.

- **With Hand held**

Please find out “Black list setting” in Hand held.

Note: if you lost a key card, you want to stop it from opening the lock with hand held; you have to re-write the lock’s information because the black list setting is changed, and then setup lock’s information again.

13.5. Low voltage alarm

If you hear 8 beeps and green light when you open the lock, which means low voltage alarm, replacing the batteries is necessary.

13.6. Door Ajar alarm

- **Condition 1**

If you hear” beep, beep,beep”, ” beep, beep,beep”..... and red light, when you close the door, because the door is not close properly,

- **Condition 2**

If you hear” beep, beep,beep”, ” beep, beep,beep”..... and red light,whenever closing or opening status, please have a check with latch sensor inside lock case or replace another lock case.